

PARTS LIST		
ITEM	QTY	DESCRIPTION
(1)	1	WMX200 M-LOK ADAPTER
(2)	2	5/16" M-LOK button head screw (not shown)
(3)	2	M-LOK T-Nut (not shown)

**Tools Needed**


- 1/4" slotted screwdriver for the shoulder bolt.
- Circlip Pliers w/ 0.046" tip dia for the retaining nut.  
E.g., Knipex 46 21 A01 SBA
- 1/8" Hex driver for M-LOK button head screws.

**1. Remove Factory Picatinny Mount**

- Optionally remove the light bezel assembly.  
This allows for easier slotted screwdriver operation.
- Use the 1/4" slotted screwdriver and the circlip pliers to unscrew the shoulder bolt and remove the factory picatinny mount (not shown).  
Keep the shoulder bolt, washers, and retaining nut for reuse in the next step.

**2. Install M-LOK Adapter**

- Reference the nearby diagram, re-assemble the kit with the M-LOK adapter (1) using the shoulder bolt, washers, and retaining nut from the previous step.  
**NOTE** the hardware order, from front to rear:  
Shoulder bolt, washers, light body, M-LOK adapter, light body, and retaining nut.
  - Use the 1/4" slotted screwdriver and the circlip pliers to tighten the shoulder bolt.
  - Re-attach the light bezel assembly if it was removed.
- NOTE:**  
Adjust the rotational resistance to the desired level by tightening / loosening the shoulder bolt.



\* Included with your Insight Technology WMX200 kit.

++ Optionally apply a small amount of silicone grease.



NAME		DATE		KOENG PN 02-003		
DRAWN	KOENG	2022/09/15	TITLE			
CHECKED			WMX200 M-LOK ADAPTER			
APPROVED	CFC		SIZE	DWG. NO.	REV.	
			A	20220915	01	
MATERIAL	FINISH	SCALE	WEIGHT	SHEET		
6061-T6	Mil. Spec Type 3 Anodized	1:1		1 of 1		